

EN

Please charge 10 minutes before first use.

DE

Bitte laden Sie 10 Minuten vor der ersten Verwendung auf.

IT

Caricare 10 minuti prima del primo utilizzo.

FR

Veillez charger 10 minutes avant la première utilisation.

ES

Por favor, cargue 10 minutos antes del primer uso.

JP

初めて使用する前に10分間充電してください。



Tail Eraser
(Supported by specific apps and tablets only)

Lenovo devices are not supported

LED Indicator

USB-C
Charging port

Customizable
Bluetooth
Shortcuts

Replaceable nib

Contents

USI 2.0 Ultra / Replacement Tip / Manual /
Charging Cable

How to Pair & Use

1. **Please charge the stylus for 10 minutes before first use.** Press either shortcut button to turn the stylus on.
2. **First-Time Pairing:** The stylus will automatically enter pairing mode when turned on for the first time.
3. **Bluetooth Connection:** Go to your tablet's **Settings > Bluetooth** to find and pair the stylus.
4. **Pairing Timeout:** If pairing is not completed after **1 minute**, the indicator light will stop flashing and pairing mode will turn off. However, the **writing function will remain fully active.**
5. **Re-enter Pairing Mode:** If the pairing mode times out before you can connect, simply turn the stylus off and on again to restart pairing.
6. **Download the "eiP" App** from the Google Play Store or scan the QR code below.



Power

Turn On : Press one of the shortcut buttons to turn on the stylus.

Turn Off : Hold both shortcut buttons until the indicator light flashes.

Tips :

For your convenience, the stylus features an auto-shutdown function. You can adjust the shutdown time in the "eiP" App.

Battery Indicator Light

Turn on: The blue light will stay lit for 10 seconds.

Turn off: The blue light will flashes 3 times, then turn off.

Bluetooth Pairing: The blue light flashes. Once connected, it will remain solid blue for 3 seconds (Please turn on the bluetooth on the tablet.) .

Pairing Mode Guide

First-Time / Disconnected State: When the stylus is not connected to a device, it will enter pairing mode automatically as soon as it powers on.

Pairing Timeout: If pairing is not completed within 1 minute, pairing mode will automatically turn off to save power. (Note: The writing function will remain fully active). To restart pairing, simply turn the stylus off and on again.

Charging: The red light remains on while charging and turns off when fully charged.

Low Battery: The red light flashes.



Magnetic Compatibility:

Some Android tablets are not magnetic. Please make sure your tablet supports magnetic attachment.

Customization Features

Shortcut Settings

You can assign shortcut button from 1 to 3 clicks using the “eiP” App to perform actions such as adjusting the brightness or volume, launching Gemini, taking a screenshot, and more.

*Note: Due to system variations across different tablet models, some functions may only work on specific devices. (Tested on Google Pixel Tablet.)

Auto-Sleep Timer

Adjust the auto-sleep time.


3 minutes






Tip Signal Adjustment

Adjust the signal strength of the stylus tip.

Level 2



	APP	Tail Button
	Squid	Eraser
	Keep Notes	Eraser
	OneNote	Eraser

* The shortcut function may change depending on the tablet and the app update.

* These features are optimized for the 2023 Google Pixel Tablet.

Attention

1. Do not use this product on surfaces other than the screen to avoid the pen tip wearing and damaging the screen.
2. Please keep the pen tip clean when using; dust or particles may affect the touch effect.
3. Due to long-term friction, the pen tip may wear out. Please replace the pen tip regularly to avoid damaging the screen.
4. Please keep the pen out of reach of children or pets to avoid accidental ingestion or other injuries.
5. The pen contains sensitive electronic components (including batteries). Please be careful when using it. If it accidentally falls, burns, bends, or comes into contact with liquids, it may cause damage to this product or personal injury. If the product is damaged, please do not use it.
6. Do not use any solution or liquid to clean this product in order to prevent the solution or liquid from entering the interior of the product and causing moisture or damage to internal components.
7. Some screen films may affect the writing experience.
8. The radiation of electronic devices may have an impact on the operation of other electronic devices and cause adverse effects and device malfunction. People who carry implanted or external electronic therapy instruments are prohibited from using them.
9. If the touch pen is not used for a long time, it is recommended to charge it once a month.

Compatibility

USI Protocol Tablet

Please ensure your tablet is compatible with USI Protocol. For more list, please visit

<https://universalstylus.org/>

Compatible Devices

Acer	Acer Chromebook Spin 314 (CP314-1HN) Acer Chromebook Spin 511 (R753TN) Acer Chromebook Spin 512 (R853TNA) Acer Chromebook Spin 513 (CP513-1H, CP513-1HL R841T, R841LT) Acer Chromebook Spin 514 (CP514-1H, CP514-1HH CP514-1W, CP514-2H) Acer Chromebook Spin 713 (CP713-2W, CP713-3W)
ASUS	ASUS Chromebook CX9 (CX9400) (some models, including North American models ending with T) ASUS Chromebook Detachable CM3 ASUS Chromebook Detachable CZ1 ASUS Chromebook Flip C436FA ASUS Chromebook Flip CM3200FM1A ASUS Chromebook Flip CM3200FVA ASUS Chromebook Flip CR1100FKA ASUS Chromebook Flip CX3 ASUS Chromebook Flip CX5 (CX5400) ASUS Chromebook Flip CX5 (CX5500) ASUS Flip C536 ASUS Flip CM5
HP	HP Chromebook x2 11 HP Chromebook X360 11 G4 Education Edition HP Chromebook x360 12b HP Chromebook x360 13c HP Chromebook x360 14b (14b-ca0xxx and FHD14b-cb0xxx models) HP Chromebook x360 14c HP Elite c1030 Chromebook
Lenovo	Lenovo Chromebook Duet Lenovo Chromebook Duet 3 Lenovo Chromebook Duet 5 Lenovo 10e Chromebook Tablet Lenovo 300e Chromebook Gen 3 Lenovo 500e Chromebook Gen 3 Lenovo IdeaPad Duet 5 Chromebook Lenovo IdeaPad Flex 5i Chromebook (13", 5) Lenovo IdeaPad Flex 5i Chromebook (13", 6) Lenovo ThinkPad C13 Yoga Gen 1
Samsung	Samsung Galaxy Chromebook 2
Other	NEC Chromebook Y1 Gen3A NEC Chromebook Y3 Dynabook Chromebook C1 Google Pixel Tablet 11"

Specification

Model	USI 2.0 Ultra
Charging Time	60 Minutes
Battery Life	40 Hours

Customer Service

service-us@lemeng.com.tw

Scan to our website

